

RD-A187 595


ELECTROLYTE CONDUCTANCE IN THE  
LIASF6-1122-TETRACHLOROETHANE-COSOLVENT SYSTEM(U) NAVAL  
SURFACE WEAPONS CENTER SILVER SPRING MD Y TRAN ET AL.


1/1

UNCLASSIFIED 81 AUG 87 NSWC/TR-87-56

F/G 7/4

NL





MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS 1963-A

(4)

NSWC TR 87-56

DTIC FILE COPY

AD-A187 595

**ELECTROLYTE CONDUCTANCE IN THE LiAsF<sub>6</sub>-1,1,2,2-TETRACHLOROETHANE-COSOLVENT SYSTEM**

BY YVONNE TRAN PATRICIA H. SMITH KATHLEEN M. O'NEILL  
STANLEY D. JAMES  
RESEARCH AND TECHNOLOGY DEPARTMENT

1 AUGUST 1987



Approved for public release, distribution is unlimited.



**NAVAL SURFACE WARFARE CENTER**

Dahlgren, Virginia 22448-5000 • Silver Spring, Maryland 20903-5000

87 12 29 30

## UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE

## REPORT DOCUMENTATION PAGE

1a REPORT SECURITY CLASSIFICATION UNCLASSIFIED		1b RESTRICTIVE MARKINGS <b>A187395-</b>			
2a SECURITY CLASSIFICATION AUTHORITY		3 DISTRIBUTION AND APPROVAL REPORT Approved for public release; distribution unlimited.			
3b DECLASSIFICATION/DOWNGRADING SCHEDULE					
4 PERFORMING ORGANIZATION REPORT NUMBER(S) NSWC TR 87-56		5 MONITORING ORGANIZATION REPORT NUMBER(S)			
6a NAME OF PERFORMING ORGANIZATION Naval Surface Weapons Center	6b OFFICE SYMBOL (If applicable) Code R33	7a NAME OF MONITORING ORGANIZATION			
6c ADDRESS (City, State and ZIP Code) 10901 New Hampshire Avenue Silver Spring, MD 20903-5000		7b ADDRESS (City, State and ZIP Code)			
8a NAME OF FUNDING SPONSORING ORGANIZATION	8b OFFICE SYMBOL (If applicable)	9 PROGRAM/PROJECT IDENTIFICATION NUMBER			
8c ADDRESS (City, State and ZIP Code)		10 SOURCE OF FUNDING NUMBER			
		PROGRAM ELEMENT NO. 62936N	PROJECT NO. X3620	CLASS NO. X3620	AGENCY CODE NO. DOD-A
11 TITLE (Include Security Classification) Electrolyte Conductance in the LiAsF <sub>6</sub> -1,1,2,2-Tetrachloroethane Co-solvent System					
12 PERSONAL AUTHORS: Tran, Yvonne; Smith, Patricia H.; O'Neill, Kathleen M.; and Turner, Stephen D.					
13a TYPE OF REPORT Final	13b TIME COPIED 2PM Nov 85	13c DATE OF REPORT (Year Month Day) Mar 87	13d PAGE COUNT 27		
14 SUPPLEMENTARY NOTATION					
15 COSATI CODES		16 SUBJECT TERMS (Continue on reverse if necessary and identify by block number) Conductivity - 1,1,2,2-tetrachloroethane Liquid Cathode			
FIELD	GROUP	SUB GROUP			
07	04				
07	03				
17 ABSTRACT (Continue on reverse if necessary and identify by block number) Conductance was measured of lithium hexafluorosulfate (LiPF <sub>6</sub> ) dried in binary mixtures of 1,1,2,2-tetrachloroethane with the following cosolvents: methyl formate, tetrahydrofuran, ethyl acetate, $\gamma$ -buterolactone, propylene carbonate, ethyl nitrite, and diethyl sulfite. The conductivity measurements were conducted at +20, +40, +60, +80, +100, +120, +140, +160, +180, +200, +220, +240, +260, +280, +300, +320, +340, +360, +380, +400, +420, +440, +460, +480, +500, +520, +540, +560, +580, +600, +620, +640, +660, +680, +700, +720, +740, +760, +780, +800, +820, +840, +860, +880, +900, +920, +940, +960, +980, +1000, +1020, +1040, +1060, +1080, +1100, +1120, +1140, +1160, +1180, +1200, +1220, +1240, +1260, +1280, +1300, +1320, +1340, +1360, +1380, +1400, +1420, +1440, +1460, +1480, +1500, +1520, +1540, +1560, +1580, +1600, +1620, +1640, +1660, +1680, +1700, +1720, +1740, +1760, +1780, +1800, +1820, +1840, +1860, +1880, +1900, +1920, +1940, +1960, +1980, +2000, +2020, +2040, +2060, +2080, +2100, +2120, +2140, +2160, +2180, +2200, +2220, +2240, +2260, +2280, +2300, +2320, +2340, +2360, +2380, +2400, +2420, +2440, +2460, +2480, +2500, +2520, +2540, +2560, +2580, +2600, +2620, +2640, +2660, +2680, +2700, +2720, +2740, +2760, +2780, +2800, +2820, +2840, +2860, +2880, +2900, +2920, +2940, +2960, +2980, +3000, +3020, +3040, +3060, +3080, +3100, +3120, +3140, +3160, +3180, +3200, +3220, +3240, +3260, +3280, +3300, +3320, +3340, +3360, +3380, +3400, +3420, +3440, +3460, +3480, +3500, +3520, +3540, +3560, +3580, +3600, +3620, +3640, +3660, +3680, +3700, +3720, +3740, +3760, +3780, +3800, +3820, +3840, +3860, +3880, +3900, +3920, +3940, +3960, +3980, +4000, +4020, +4040, +4060, +4080, +4100, +4120, +4140, +4160, +4180, +4200, +4220, +4240, +4260, +4280, +4300, +4320, +4340, +4360, +4380, +4400, +4420, +4440, +4460, +4480, +4500, +4520, +4540, +4560, +4580, +4600, +4620, +4640, +4660, +4680, +4700, +4720, +4740, +4760, +4780, +4800, +4820, +4840, +4860, +4880, +4900, +4920, +4940, +4960, +4980, +5000, +5020, +5040, +5060, +5080, +5100, +5120, +5140, +5160, +5180, +5200, +5220, +5240, +5260, +5280, +5300, +5320, +5340, +5360, +5380, +5400, +5420, +5440, +5460, +5480, +5500, +5520, +5540, +5560, +5580, +5600, +5620, +5640, +5660, +5680, +5700, +5720, +5740, +5760, +5780, +5800, +5820, +5840, +5860, +5880, +5900, +5920, +5940, +5960, +5980, +6000, +6020, +6040, +6060, +6080, +6100, +6120, +6140, +6160, +6180, +6200, +6220, +6240, +6260, +6280, +6300, +6320, +6340, +6360, +6380, +6400, +6420, +6440, +6460, +6480, +6500, +6520, +6540, +6560, +6580, +6600, +6620, +6640, +6660, +6680, +6700, +6720, +6740, +6760, +6780, +6800, +6820, +6840, +6860, +6880, +6900, +6920, +6940, +6960, +6980, +7000, +7020, +7040, +7060, +7080, +7100, +7120, +7140, +7160, +7180, +7200, +7220, +7240, +7260, +7280, +7300, +7320, +7340, +7360, +7380, +7400, +7420, +7440, +7460, +7480, +7500, +7520, +7540, +7560, +7580, +7600, +7620, +7640, +7660, +7680, +7700, +7720, +7740, +7760, +7780, +7800, +7820, +7840, +7860, +7880, +7900, +7920, +7940, +7960, +7980, +8000, +8020, +8040, +8060, +8080, +8100, +8120, +8140, +8160, +8180, +8200, +8220, +8240, +8260, +8280, +8300, +8320, +8340, +8360, +8380, +8400, +8420, +8440, +8460, +8480, +8500, +8520, +8540, +8560, +8580, +8600, +8620, +8640, +8660, +8680, +8700, +8720, +8740, +8760, +8780, +8800, +8820, +8840, +8860, +8880, +8900, +8920, +8940, +8960, +8980, +9000, +9020, +9040, +9060, +9080, +9100, +9120, +9140, +9160, +9180, +9200, +9220, +9240, +9260, +9280, +9300, +9320, +9340, +9360, +9380, +9400, +9420, +9440, +9460, +9480, +9500, +9520, +9540, +9560, +9580, +9600, +9620, +9640, +9660, +9680, +9700, +9720, +9740, +9760, +9780, +9800, +9820, +9840, +9860, +9880, +9900, +9920, +9940, +9960, +9980, +0000, +0020, +0040, +0060, +0080, +0100, +0120, +0140, +0160, +0180, +0200, +0220, +0240, +0260, +0280, +0300, +0320, +0340, +0360, +0380, +0400, +0420, +0440, +0460, +0480, +0500, +0520, +0540, +0560, +0580, +0600, +0620, +0640, +0660, +0680, +0700, +0720, +0740, +0760, +0780, +0800, +0820, +0840, +0860, +0880, +0900, +0920, +0940, +0960, +0980, +1000, +1020, +1040, +1060, +1080, +1100, +1120, +1140, +1160, +1180, +1200, +1220, +1240, +1260, +1280, +1300, +1320, +1340, +1360, +1380, +1400, +1420, +1440, +1460, +1480, +1500, +1520, +1540, +1560, +1580, +1600, +1620, +1640, +1660, +1680, +1700, +1720, +1740, +1760, +1780, +1800, +1820, +1840, +1860, +1880, +1900, +1920, +1940, +1960, +1980, +2000, +2020, +2040, +2060, +2080, +2100, +2120, +2140, +2160, +2180, +2200, +2220, +2240, +2260, +2280, +2300, +2320, +2340, +2360, +2380, +2400, +2420, +2440, +2460, +2480, +2500, +2520, +2540, +2560, +2580, +2600, +2620, +2640, +2660, +2680, +2700, +2720, +2740, +2760, +2780, +2800, +2820, +2840, +2860, +2880, +2900, +2920, +2940, +2960, +2980, +3000, +3020, +3040, +3060, +3080, +3100, +3120, +3140, +3160, +3180, +3200, +3220, +3240, +3260, +3280, +3300, +3320, +3340, +3360, +3380, +3400, +3420, +3440, +3460, +3480, +3500, +3520, +3540, +3560, +3580, +3600, +3620, +3640, +3660, +3680, +3700, +3720, +3740, +3760, +3780, +3800, +3820, +3840, +3860, +3880, +3900, +3920, +3940, +3960, +3980, +4000, +4020, +4040, +4060, +4080, +4100, +4120, +4140, +4160, +4180, +4200, +4220, +4240, +4260, +4280, +4300, +4320, +4340, +4360, +4380, +4400, +4420, +4440, +4460, +4480, +4500, +4520, +4540, +4560, +4580, +4600, +4620, +4640, +4660, +4680, +4700, +4720, +4740, +4760, +4780, +4800, +4820, +4840, +4860, +4880, +4900, +4920, +4940, +4960, +4980, +5000, +5020, +5040, +5060, +5080, +5100, +5120, +5140, +5160, +5180, +5200, +5220, +5240, +5260, +5280, +5300, +5320, +5340, +5360, +5380, +5400, +5420, +5440, +5460, +5480, +5500, +5520, +5540, +5560, +5580, +5600, +5620, +5640, +5660, +5680, +5700, +5720, +5740, +5760, +5780, +5800, +5820, +5840, +5860, +5880, +5900, +5920, +5940, +5960, +5980, +6000, +6020, +6040, +6060, +6080, +6100, +6120, +6140, +6160, +6180, +6200, +6220, +6240, +6260, +6280, +6300, +6320, +6340, +6360, +6380, +6400, +6420, +6440, +6460, +6480, +6500, +6520, +6540, +6560, +6580, +6600, +6620, +6640, +6660, +6680, +6700, +6720, +6740, +6760, +6780, +6800, +6820, +6840, +6860, +6880, +6900, +6920, +6940, +6960, +6980, +7000, +7020, +7040, +7060, +7080, +7100, +7120, +7140, +7160, +7180, +7200, +7220, +7240, +7260, +7280, +7300, +7320, +7340, +7360, +7380, +7400, +7420, +7440, +7460, +7480, +7500, +7520, +7540, +7560, +7580, +7600, +7620, +7640, +7660, +7680, +7700, +7720, +7740, +7760, +7780, +7800, +7820, +7840, +7860, +7880, +7900, +7920, +7940, +7960, +7980, +8000, +8020, +8040, +8060, +8080, +8100, +8120, +8140, +8160, +8180, +8200, +8220, +8240, +8260, +8280, +8300, +8320, +8340, +8360, +8380, +8400, +8420, +8440, +8460, +8480, +8500, +8520, +8540, +8560, +8580, +8600, +8620, +8640, +8660, +8680, +8700, +8720, +8740, +8760, +8780, +8800, +8820, +8840, +8860, +8880, +8900, +8920, +8940, +8960, +8980, +9000, +9020, +9040, +9060, +9080, +9100, +9120, +9140, +9160, +9180, +9200, +9220, +9240, +9260, +9280, +9300, +9320, +9340, +9360, +9380, +9400, +9420, +9440, +9460, +9480, +9500, +9520, +9540, +9560, +9580, +9600, +9620, +9640, +9660, +9680, +9700, +9720, +9740, +9760, +9780, +9800, +9820, +9840, +9860, +9880, +9900, +9920, +9940, +9960, +9980, +0000, +0020, +0040, +0060, +0080, +0100, +0120, +0140, +0160, +0180, +0200, +0220, +0240, +0260, +0280, +0300, +0320, +0340, +0360, +0380, +0400, +0420, +0440, +0460, +0480, +0500, +0520, +0540, +0560, +0580, +0600, +0620, +0640, +0660, +0680, +0700, +0720, +0740, +0760, +0780, +0800, +0820, +0840, +0860, +0880, +0900, +0920, +0940, +0960, +0980, +1000, +1020, +1040, +1060, +1080, +1100, +1120, +1140, +1160, +1180, +1200, +1220, +1240, +1260, +1280, +1300, +1320, +1340, +1360, +1380, +1400, +1420, +1440, +1460, +1480, +1500, +1520, +1540, +1560, +1580, +1600, +1620, +1640, +1660, +1680, +1700, +1720, +1740, +1760, +1780, +1800, +1820, +1840, +1860, +1880, +1900, +1920, +1940, +1960, +1980, +2000, +2020, +2040, +2060, +2080, +2100, +2120, +2140, +2160, +2180, +2200, +2220, +2240, +2260, +2280, +2300, +2320, +2340, +2360, +2380, +2400, +2420, +2440, +2460, +2480, +2500, +2520, +2540, +2560, +2580, +2600, +2620, +2640, +2660, +2680, +2700, +2720, +2740, +2760, +2780, +2800, +2820, +2840, +2860, +2880, +2900, +2920, +2940, +2960, +2980, +3000, +3020, +3040, +3060, +3080, +3100, +3120, +3140, +3160, +3180, +3200, +3220, +3240, +3260, +3280, +3300, +3320, +3340, +3360, +3380, +3400, +3420, +3440, +3460, +3480, +3500, +3520, +3540, +3560, +3580, +3600, +3620, +3640, +3660, +3680, +3700, +3720, +3740, +3760, +3780, +3800, +3820, +3840, +3860, +3880, +3900, +3920, +3940, +3960, +3980, +4000, +4020, +4040, +4060, +4080, +4100, +4120, +4140, +4160, +4180, +4200, +4220, +4240, +4260, +4280, +4300, +4320, +4340, +4360, +4380, +4400, +4420, +4440, +4460, +4480, +4500, +4520, +4540, +4560, +4580, +4600, +4620, +4640, +4660, +4680, +4700, +4720, +4740, +4760, +4780, +4800, +4820, +4840, +4860, +4880, +4900, +4920, +4940, +4960, +4980, +5000, +5020, +5040, +5060, +5080, +5100, +5120, +5140, +5160, +5180, +5200, +5220, +5240, +5260, +5280, +5300, +5320, +5340, +5360, +5380, +5400, +5420, +5440, +5460, +5480, +5500, +5520, +5540, +5560, +5580, +5600, +5620, +5640, +5660, +5680, +5700, +5720, +5740, +5760, +5780, +5800, +5820, +5840, +5860, +5880, +5900, +5920, +5940, +5960, +5980, +6000, +6020, +6040, +6060, +6080, +6100, +6120, +6140, +6160, +6180, +6200, +6220, +6240, +6260, +6280, +6300, +6320, +6340, +6360, +6380, +6400, +6420, +6440, +6460, +6480, +6500, +6520, +6540, +6560, +6580, +6600, +6620, +6640, +6660, +6680, +6700, +6720, +6740, +6760, +6780, +6800, +6820, +6840, +6860, +6880, +6900, +6920, +6940, +6960, +6980, +7000, +7020, +7040, +7060, +7080, +7100, +7120, +7140, +7160, +7180, +7200, +7220, +7240, +7260, +7280, +7300, +7320, +7340, +7360, +7380, +7400, +7420, +7440, +7460, +7480, +7500, +7520, +7540, +7560, +7580, +7600, +7620, +7640, +7660, +7680, +7700, +7720, +7740, +7760, +7780, +7800, +7820, +7840, +7860, +7880, +7900, +7920, +7940, +7960, +7980, +8000, +8020, +8040, +8060, +8080, +8100, +8120, +8140, +8160, +8180, +8200, +8220, +8240, +8260, +8280, +8300, +8320, +8340, +8360, +8380, +8400, +8420, +8440, +8460, +8480, +8500, +8520, +8540, +8560, +8580, +8600, +8620, +8640, +8660, +8680, +8700, +8720, +8740, +8760, +8780, +8800, +8820, +8840, +8860, +8880, +8900, +8920, +8940, +8960, +8980, +9000, +9020, +9040, +9060, +9080, +9100, +9120, +9140, +9160, +9180, +9200, +9220, +9240, +9260, +9280, +9300, +9320, +9340, +9360, +9380, +9400, +9420, +9440, +9460, +9480, +9500, +9520, +9540, +9560, +9580, +9600, +9620, +9640, +9660, +9680, +9700, +9720, +9740, +9760, +9780, +9800, +9820, +9840, +9860, +9880, +9900, +9920, +9940, +9960, +9980, +0000, +0020, +0040, +0060, +0080, +0100, +0120, +0140, +0160, +0180, +0200, +0220, +0240, +0260, +0280, +0300, +0320, +0340, +0360, +0380, +0400, +0420, +0440, +0460, +0480, +0500, +0520, +0540, +0560, +0580, +0600, +0620, +0640, +0660, +0680, +0700, +0720, +0740, +0760, +0780, +0800, +0820, +0840, +0860, +0880, +0900, +0920, +0940, +0960, +0980, +1000, +1020, +1040, +1060, +1080, +1100, +1120, +1140, +1160, +1180, +1200, +1220, +1240, +1260, +1280, +1300, +1320, +1340, +1360, +1380, +1400, +1420, +1440, +1460, +1480, +1500, +1520, +1540, +1560, +1580, +1600, +1620, +1640, +1660, +1680, +1700, +1720, +1740, +1760, +1780, +1800, +1820, +1840, +1860, +1880, +1900, +1920, +1940, +1960, +1980, +2000, +2020, +2040, +2060, +2080, +2100, +2120, +2140, +2160, +2180, +2200, +2220, +2240, +2260, +2280, +2300, +2320, +2340, +2360, +2380, +2400, +2420, +2440, +2460, +2480, +2500, +2520, +2540, +2560, +2580, +2600, +2620, +2640, +2660, +2680, +2700, +2720, +2740, +2760, +2780, +2800, +2820, +2840, +2860, +2880, +2900, +2920, +2940, +2960, +2980, +3000, +3020, +3040, +3060, +3080, +3100, +3120, +3140, +3160, +3180, +3200, +3220, +3240, +3260, +3280, +3300, +3320, +3340, +3360, +3380, +3400, +3420, +3440, +3460, +3480, +3500, +3520, +3540, +3560, +3580, +3600, +3620, +3640, +3660, +3680, +3700, +3720, +3740, +3760, +3780, +3800, +3820, +3840, +3860, +3880, +3900, +3920, +3940, +3960, +3980, +					

UNCLASSIFIED  
SECURITY CLASSIFICATION OF THIS PAGE

UNCLASSIFIED  
SECURITY CLASSIFICATION OF THIS PAGE

## **FOREWORD**

In recent work in our laboratories, 1,1,2,2-tetrachloroethane was selected as an alternate cathode material for possibly safer lithium batteries. However, it is a poor solvent medium for lithium salts. A cosolvent is needed to dissolve the salt and raise the conductivity of the electrolyte. A number of non-aqueous dipolar aprotic liquids were investigated as possible cosolvents for 1,1,2,2,-tetrachloroethane. This report presents the conductivity study of these electrolyte systems as a function of temperature between -20 and 25°C.

This work was supported by the Independent Research and Exploratory Development programs at NSWC.

Approved by:

*Jack R. Dixon*  
JACK R. DIXON, Head  
Materials Division



CONTENTS

	<u>Page</u>
INTRODUCTION . . . . .	1
EXPERIMENTAL . . . . .	1
RESULTS AND DISCUSSION . . . . .	2
CONCLUSIONS . . . . .	3
REFERENCES . . . . .	15
DISTRIBUTION . . . . .	(1)

## ILLUSTRATIONS

<u>Figure</u>		<u>Page</u>
1	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% METHYL FORMATE SOLUTIONS . . . . .	4
2	SPECIFIC CONDUCTANCE OF 75% 1,1,2,2-TETRACHLOROETHANE, 25% METHYL FORMATE SOLUTIONS . . . . .	5
3	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% TETRAHYDROFURAN SOLUTIONS . . . . .	5
4	SPECIFIC CONDUCTANCE OF 75% 1,1,2,2-TETRACHLOROETHANE, 25% TETRAHYDROFURAN SOLUTIONS . . . . .	6
5	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% ETHYL ACETATE SOLUTIONS . . . . .	6
6	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% $\gamma$ -BUTYROLACTONE SOLUTIONS . . . . .	7
7	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% PROPYLENE CARBONATE SOLUTIONS . . . . .	7
8	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% ACETONITRILE SOLUTIONS . . . . .	8
9	SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% DIMETHYL SULFITE SOLUTIONS . . . . .	9

## TABLES

<u>Table</u>	<u>Page</u>
1 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% METHYL FORMATE . . . . .	10
2 CONDUCTANCE OF LiAsF <sub>6</sub> IN 75% 1,1,2,2-TETRACHLOROETHANE, 25% METHYL FORMATE . . . . .	10
3 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% TETRAHYDROFURAN . . . . .	11
4 CONDUCTANCE OF LiAsF <sub>6</sub> IN 75% 1,1,2,2-TETRACHLOROETHANE, 25% TETRAHYDROFURAN . . . . .	11
5 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% ETHYL ACETATE . . . . .	12
6 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% $\gamma$ -BUTYROLACTONE . . . . .	12
7 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% PROPYLENE CARBONATE . . . . .	13
8 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% ACETONITRILE . . . . .	13
9 CONDUCTANCE OF LiAsF <sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE, 50% DIMETHYL SULFITE . . . . .	14
10 CORRELATION OF HIGHEST OBTAINABLE LiAsF <sub>6</sub> ELECTROLYTE CONDUCTANCES WITH CALCULATED VALUES OF DIELECTRIC CONSTANT AND VISCOSITY OF 50% TETRACHLOROETHANE/COSOLVENT MIXTURES at 25°C . . . . .	14

## INTRODUCTION

In search of a lithium battery system safer than the present energetic SO<sub>2</sub> and sulfur oxychlorides, we investigated 1,1,2,2-tetrachloroethane as a new cathode because of its low toxicity and reduced shock sensitivity with lithium.<sup>1</sup> Though this halocarbon liquid is an active cathode, it is a poor solvent for lithium salts. Therefore, the viability of this new cathode demands the presence of a cosolvent.

Our investigation focused on finding halocarbon/cosolvent/ LiAsF<sub>6</sub> systems that are highly conductive over the temperature range of -20 to 25°C. This report presents the results of our studies on conductivities of LiAsF<sub>6</sub> solutions in the binary mixtures of 1,1,2,2-tetrachloroethane and the following cosolvents: acetonitrile, methyl formate, tetrahydrofuran, ethyl acetate, γ-butyrolactone, propylene carbonate and dimethyl sulfite.

## EXPERIMENTAL

The reagents used for this experiment were:

LiAsF<sub>6</sub>, Electrochemical Grade, U.S. Steel Agri-Chemicals

ethyl acetate (EtOAc), anhydrous 99 percent; γ-butyrolactone (γBL), 99 percent; tetrahydrofuran (THF), 99.9 percent; 1,1,2,2-tetrachloroethane (TCE), 98 percent; dimethyl sulfite (DMSI), 99.7 percent: Aldrich Chemical Co.

propylene carbonate (PC); water percent 0.006 percent: Burdick and Jackson Laboratories

acetonitrile (AN), 99 percent: Fisher Scientific

methyl formate (MF): MCB MX-1041-30 Honeywell Grade.

A Yellow Spring Instrument borosilicate dip-type cell (model no. 3403) connected to a YSI Conductance Resistance Meter (model no. 34) was used to measure the resistance of the solution. The YSI model 34 applies a 1 volt square wave to the sample under test. The model 3403 cell constant was determined to be 1.10 cm<sup>-1</sup>. The specific conductance of the electrolyte was calculated using the resistance-specific conductance relationship,<sup>2</sup>

$$\kappa = C / R \quad (\Omega^{-1} \text{ cm}^{-1}) \quad (1)$$

where  $\kappa$  = specific conductance ( $\Omega^{-1} \text{ cm}^{-1}$ )  
C = cell constant ( $\text{cm}^{-1}$ )  
R = measured resistance ( $\Omega$ )

Most of the solution resistances (R) measured in this work were below 2000  $\Omega$  where the YSI model 34's output frequency is 2000 Hz. In the few measurements above 2000  $\Omega$  the frequency was 177 Hz.

Experiments were performed in a dry room in which the humidity did not exceed 0.5%. TCE-cosolvent mixtures were made up in terms of volume percent, e.g. a 25% TCE-75% THF mixture was made by combining 25 volumes of TCE with 75 volumes of THF. Solubility tests were then made to estimate maximum LiAsF<sub>6</sub> concentration achievable in these TCE/cosolvent solutions at room temperature. After this concentration was determined, a concentrated LiAsF<sub>6</sub> stock solution was prepared for subsequent dilution with the TCE-cosolvent mixture.

The prepared solutions were transferred into 16 x 100 mm Pyrex test tubes. A 5 ml sample was required for the conductivity test. Protected with Parafilm, these test tubes were placed in a constant temperature bath for at least an hour to reach thermal equilibrium at the set temperature. The constant temperature bath was a Haake A81 equipped with a digital read-out monitoring the temperature with an accuracy of  $\pm 0.01^\circ\text{C}$ . The bath liquid was a glycol-alcohol-water mixture appropriate to the particular temperature. The temperatures selected for the conductivity measurements were 25, 0 and -20°C.

Conductivity measurements were performed as follows: The conductivity cell was placed in the vessel that contained the solution studied. After 1 to 2 minutes, the constant solution resistance was read from the YSI Conductance Resistance Meter display. Using the known cell constant, the specific conductance of the electrolyte was obtained using equation (1). After each reading, the conductivity cell was first rinsed with the pure cosolvent then with acetone afterwards to remove any adhering salt. A heat gun was employed to air-dry the conductivity cell. Specific conductances were plotted against molar concentrations at 25, 0 and -20°C to generate Figures 1 through 9.

## RESULTS AND DISCUSSION

Tables 1 through 9 list the conductivity data at 25, 0 and -20°C. Figures 1 through 9 are plots of the specific conductances versus molar concentrations at these temperatures. Conductance data were measured up to the limit of salt solubility. A maximum specific conductivity was obtained for most plots. The solubility of LiAsF<sub>6</sub> in TCE solutions containing 25% THF, 25% MF or 50% AN is low. In these cases (Figures 2, 4 and 8) no maxima were observed in the accessible concentration range.

On cooling below room temperature, solutions of LiAsF<sub>6</sub> in TCE mixtures containing 50%  $\gamma$ BL, 50% THF or 50% AN become supersaturated. At 0°C, 50% AN solution experiences salt precipitation at concentrations of 0.392 M or greater. At -20°C, similar behavior is observed in 50% THF solution at molar concentrations above 1.35 M. Conductance data of 50%  $\gamma$ BL solution with concentrations above 0.752 M are not reproducible at 0°C due probably to salt separation. At -20°C, this solution freezes at 0.846 M. In all cases,

electrolyte conductance decreases with decreasing temperature as shown in Figures 1 through 9. Lowering the temperature causes a decrease in ionic mobility. At 25°C the ranking of the highest specific conductivities obtained with 50% 1,1,2,2-tetrachloroethane, 50% cosolvent solutions is arranged as PC <  $\gamma$ BL < THF = DMSI < EtOAc < MF = AN. At 0°C, the conductivity ranking is PC <  $\gamma$ BL < DMSI < THF < EtOAc < AN < MF. At -20°C, the conductivity order is PC <  $\gamma$ BL < DMSI < THF < EtOAc < MF.

To understand this ordering, a comparison was made between the maximum specific conductance of the solution and its calculated dielectric constant and viscosity. (The dielectric constant  $\epsilon$  and the viscosity  $\eta$  of the electrolyte are known to strongly affect conductivity by influencing the number and mobility respectively of ionic species.) The following equation<sup>3</sup> were used to generate Table 10:

$$\text{dielectric constant} = y_1 \epsilon_1 + y_2 \epsilon_2 + \dots \\ \text{of mixture}$$

where  $y_i$ ,  $\epsilon_i$  are volume fraction and dielectric constant of component i

$$\text{viscosity of mixture} = \eta_1^{x_1} \eta_2^{x_2} \dots$$

where  $x_i$ ,  $\eta_i$  are mole fraction and viscosity of component i

Although there was no direct correlation, one trend was observed; the viscosity of the cosolvent (and hence the solution) is more important than the dielectric constant of cosolvent/solution. Thus PC or  $\gamma$ BL solutions were not the most conductive even though they have the highest dielectric constants.

We observed a decrease in solution conductivity as we decreased the volume percent of the cosolvent in 1,1,2,2-tetrachloroethane mixtures. Figures 1 through 4 illustrate this effect in methyl formate and tetrahydrofuran. As discussed above, the controlling factor is probably the higher viscosity of mixtures rich in tetrachloroethane. We also observed that for cosolvents of high dielectric constants, the highest electrolyte conductivities occurred at lower salt concentration ( $C < 1.0$  M) as in PC,  $\gamma$ BL, AN and DMSI, while with lower dielectric constant cosolvent (MF, THF and EtOAc) the maxima in conductance shifted to salt concentrations above 1.0 M. This is illustrated in Table 11. Similar observations on other systems have been reported in the literature.<sup>3</sup>

## CONCLUSIONS

$\text{LiAsF}_6$  solutions in 50:50 volume mixtures of 1,1,2,2-tetrachloroethane with acetonitrile, methyl formate are more conductive than such solutions with propylene carbonate,  $\gamma$ -butyrolactone, tetrahydrofuran, dimethyl sulfite and ethyl acetate. At 25°C, the maximum specific conductances of 50 volume percent mixtures of 1,1,2,2-tetrachloroethane with acetonitrile, and methyl formate solutions are  $12.6 \times 10^{-3} \Omega^{-1}\text{cm}^{-1}$  at 0.653 M, and  $12.5 \times 10^{-3} \Omega^{-1}\text{cm}^{-1}$  at 1.40 M respectively.




FIGURE 1. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% METHYL FORMATE SOLUTIONS




FIGURE 2. SPECIFIC CONDUCTANCE OF 75% 1,1,2,2-TETRACHLOROETHANE, 25% METHYL FORMATE SOLUTIONS




FIGURE 3. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% TETRAHYDROFURAN SOLUTIONS




FIGURE 4. SPECIFIC CONDUCTANCE OF 75% 1,1,2,2-TETRACHLOROETHANE, 25% TETRAHYDROFURAN SOLUTIONS




FIGURE 5. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% ETHYL ACETATE SOLUTIONS




FIGURE 6. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50%  $\gamma$ -BUTYROLACTONE SOLUTIONS




FIGURE 7. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% PROPYLENE CARBONATE SOLUTIONS




FIGURE 8. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% ACETONITRILE SOLUTIONS




FIGURE 9. SPECIFIC CONDUCTANCE OF 50% 1,1,2,2-TETRACHLOROETHANE, 50% DIMETHYL SULFITE SOLUTIONS

TABLE 1. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50% METHYL FORMATE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.200	1.27	1.61	1.57
0.400	2.80	3.72	4.28
0.600	4.17	5.50	6.89
0.800	4.87	6.83	9.05
1.00	5.88	7.97	11.0
1.20	6.32	8.53	12.0
1.40	6.18	8.80	12.5
1.60	5.19	8.46	12.3
1.80	4.85	7.97	11.8
2.00	4.18	7.24	10.4

TABLE 2. CONDUCTANCE OF LiAsF<sub>6</sub> IN 75% 1,1,2,2-TETRACHLOROETHANE,  
25% METHYL FORMATE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.100	0.326	0.375	0.404
0.200	0.741	0.857	0.973
0.300	1.15	1.38	1.58
0.400	1.50	1.84	2.13
0.500	1.77	2.24	2.66
0.600	2.03	2.58	3.22
0.700	2.28	2.82	3.53
0.800	2.28	2.86	3.79
0.900	2.44	3.00	3.85
1.00	2.38	3.02	3.85

TABLE 3. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50% TETRAHYDROFURAN

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{ cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.150	0.762	0.945	1.07
0.300	1.39	1.87	2.18
0.450	1.86	2.61	3.24
0.600	2.18	3.30	4.16
0.750	2.58	3.73	4.82
0.900	2.75	3.99	5.30
1.05	2.76	4.06	5.54
1.20	2.63	3.89	5.50
1.35	—	3.85	5.48
1.50	—	3.47	5.30

TABLE 4. CONDUCTANCE OF LiAsF<sub>6</sub> IN 75% 1,1,2,2-TETRACHLOROETHANE,  
25% TETRAHYDROFURAN

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{ cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.0500	0.251	0.336	0.370
0.100	0.550	0.612	0.718
0.150	0.701	0.828	0.949
0.200	0.909	1.07	1.27
0.250	1.14	1.37	1.51
0.300	1.35	1.57	1.78
0.350	1.49	1.76	2.01
0.400	1.61	1.88	2.26
0.450	1.81	2.12	2.40
0.500	1.96	2.24	2.55

TABLE 5. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50% ETHYL ACETATE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{ cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.140	0.498	0.697	0.851
0.280	1.04	1.49	1.96
0.420	1.55	2.24	3.13
0.560	1.96	3.04	4.14
0.700	2.52	3.63	5.07
0.840	2.86	4.04	5.76
0.980	3.02	4.30	6.11
1.12	2.93	4.28	6.18
1.26	2.23	3.93	5.88
1.40	1.82	3.19	5.42

TABLE 6. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50%  $\gamma$ -BUTYROLACTONE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{ cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.0940	0.383	0.720	1.28
0.188	0.626	1.20	2.20
0.282	0.774	1.53	2.84
0.376	0.898	1.80	3.45
0.470	1.06	2.00	3.81
0.564	1.17	2.17	4.10
0.658	1.15	2.19	4.30
0.752	1.09	2.08	4.40
0.846	—	—	4.42
0.940	—	—	4.38

TABLE 7. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50% PROPYLENE CARBONATE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{cm}^{-1} \times 10^3$		
	-20°C	0°C	25°C
0.0935	0.266	0.587	1.14
0.187	0.444	0.915	1.88
0.280	0.521	1.16	2.42
0.374	0.603	1.34	2.77
0.468	0.610	1.38	3.00
0.561	0.599	1.44	3.16
0.654	0.586	1.39	3.17
0.748	0.542	1.33	3.14
0.842	0.572	1.32	3.07
0.935	0.547	1.28	2.90

TABLE 8. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2- TETRACHLOROETHANE,  
50% ACETONITRILE

SALT CONCENTRATION (M' ES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{cm}^{-1} \times 10^3$	
	0°C	25°C
0.0653	1.89	2.78
0.131	3.27	4.89
0.196	4.44	6.63
0.261	5.34	7.75
0.327	6.18	9.32
0.392	-	10.1
0.457	-	11.3
0.522	-	11.6
0.588	-	12.1
0.653	-	12.6

TABLE 9. CONDUCTANCE OF LiAsF<sub>6</sub> IN 50% 1,1,2,2-TETRACHLOROETHANE,  
50% DIMETHYL SULFITE

SALT CONCENTRATION (MOLES/LITER)	SPECIFIC CONDUCTANCE, $\Omega^{-1} \text{cm}^{-1} \times 10^3$		
	-20°C	= 0°C	25°C
0.152	0.878	1.44	2.23
0.304	1.41	2.33	3.51
0.456	1.72	2.93	4.66
0.608	1.86	3.27	5.07
0.760	1.89	3.45	5.61
0.911	1.82	3.36	5.39
1.06	1.70	3.14	5.20
1.22	1.15	2.90	4.95
1.37	1.32	2.56	4.58
1.52	1.04	2.18	4.04

TABLE 10. CORRELATION OF HIGHEST OBTAINABLE LiAsF<sub>6</sub> ELECTROLYTE CONDUCTANCES  
WITH CALCULATED VALUES OF DIELECTRIC CONSTANT AND VISCOSITY OF 50%  
TETRACHLOROETHANE/COSOLVENT MIXTURES AT 25°C

COSOLVENT	COSOLVENT		MIXTURE		HIGHEST CONDUCTANCE $x(\Omega^{-1} \text{cm}^{-1} \times 10^3)$
	$\epsilon^*$	$\eta^*, \text{cP}$	$\epsilon$	$\eta, \text{cP}$	
AN	35.95	0.3409	22.1	0.598	12.6
MF	2.05(20°C)	0.3298	8.18	0.622	12.5
EtOAc	6.02**	0.4546**	7.11	0.902	6.18
DMSI	22.5	0.7715	15.3	1.156	5.61
THF	7.39(23.3°C)	0.46	7.80	0.843	5.50
$\gamma$ BL	39.1	1.72	23.6	1.79	4.42
PC	64.4†	2.53†	38.3	2.20	3.17
1,1,2,2-TCE	8.2†	1.844†			

\* Reference 3 unless otherwise noted

\*\* Reference 4

† Reference 5

REFERENCES

1. O'Neill, K. M.; James, S. D.; and Smith, P. H., New Liquid Cathodes for Lithium Batteries--Part A, Halocarbons, NSWC TR 84-178, May 1984.
2. Fuoss, R. M., Electrolytic Conductance, Interscience Publisher, Inc., London, 1959, p. 229.
3. Blomgren, G. E., Properties of Electrolytes in Lithium Batteries, Gabano, J. P., Ed., Academic Press, Inc., London, 1983.
4. Maryott, A. E. and Smith, R. E., Table of Dielectric Constants of Pure Liquids, NBS Circular 514, U. S. Government Printing Office, Washington, D.C., 1951.
5. Dean, J. A., Lange's Handbook of Chemistry, Eleventh Edition, McGraw-Hill Book Co., Inc., New York, 1973.

## DISTRIBUTION

<u>Copies</u>	<u>Copies</u>		
Defense Technical Information Center Cameron Station Alexandria, VA 22304-6145	12	Naval Underwater Systems Center Attn: T. Black (Code 3642) J. Moden (Code SB332) Newport, RI 02840	1
Institute for Defense Analyses R&E Support Division 400 Army-Navy Drive Arlington, VA 22202	1	David W. Taylor Naval Ship R & D Center Attn: A. B. Neild (Code 2723) W. J. Levendahl (Code 2703) J. Woerner (Code 2724) H. R. Urbach (Code 2724)	1
Commander Space and Naval Warfare Systems Command Washington, DC 20363-5100	1	Annapolis Laboratory Annapolis, MD 21402	1
Office of Naval Research 800 N. Quincy Street Arlington, VA 22217	2	Air Force of Scientific Research Attn: R. A. Osteryoung Directorate of Chemical Science 1400 Wilson Boulevard Arlington, VA 22209	1
Naval Research Laboratory Attn: Dr. Fred Saalfeld (Code NRL 6100) A. Simon (Code NRL 6130) 4555 Overlook Avenue, S.W. Chemistry Division Washington, DC 20360	1	Air Force Aero Propulsion Laboratory Attn: W. S. Bishop (Code AFAPL/POE-1) J. Lander (Code AFAPL/POE-1)	1
Naval Electronics Systems Command Attn: A. H. Sobel (Code PME 124-31) T. Sliwa (Code NAVEX-01K) Washington, DC 20360	1	Wright-Patterson AFB, OH 45433	1
Naval Ocean Systems Center Attn: Code 922 Dr. S. Spazk (Code 6343) Dr. S. D. Yamamoto (Code 513) San Diego, CA 92152	1	Office of Chief of Research and Development Department of the Army Attn: Dr. S. J. Magram Energy Conversion Branch Room 410, Highland Building Washington, DC 20315	1
Naval Coastal Systems Center Attn: Library Panama City, FL 32407	1	U. S. Army Research Office Attn: B. F. Spielvogel P. O. Box 12211 Research Triangle Park, NC 27709	1

## DISTRIBUTION (Cont.)

<u>Copies</u>	<u>Copies</u>		
U. S. Army Electronics Command Attn: A. J. Legath (Code DRSEL-TL-P) E. Brooks (Code DRSEL-TL-PD) G. DiMasi Dr. W. K. Behl Fort Monmouth, NJ 07703	1	NASA Goddard Space Flight Center Attn: T. Hennigan (Code 716.2) Greenbelt, MD 20771	1
Army Material and Mechanical Research Center Attn: J. J. DeMarco Watertown, MA 02172	1	NASA Lewis Research Center Attn: J. S. Fordyce (Code MS 309-1) H. J. Schwartz (Code MS 309-1) 2100 Brookpark Road Cleveland, OH 44135	1
USA Mobility Equipment Research and Development Command Attn: J. Sullivan (Code DRXFB) (Code DRME-EC) Electrochemical Division Fort Belvoir, VA 22060	1	Bell Laboratories Attn: Dr. J. J. Auborn 600 Mountain Avenue Murray Hill, NJ 07974	1
Edgewood Arsenal Attn: Library Aberdeen Proving Ground Aberdeen, MD 21010	1	California Institute of Technology Attn: Library Jet Propulsion Laboratory 4800 Oak Grove Drive Pasadena, CA 91103	1
Harry Diamond Laboratory Attn: J. T. Nelson (Code DRKDO-RDD) Chief, Power Supply Branch 2800 Powder Mill Road Adelphi, MD 20783-1145	1	Sandia Laboratories Attn: R. D. Wehrle (Code 2522) B. H. Van Domelan (Code 2523) Albuquerque, NM 87115	1
Department of Energy Attn: Dr. A. Landgrebe (Code MS E-463) Energy Research and Development Agency Division of Applied Technology Washington, DC 20545	1	Catalyst Research Corporation Attn: G. Bowser N. Issacs F. Tepper 1421 Clarkview Road Baltimore, MD 21209	1
NASA Headquarters Attn: Dr. J. H. Ambrus (Code RTS-6) Washington, DC 20546	1	EIC Corporation Attn: G. L. Holleck 55 Chapel Street Newton, MA 02158	1

## DISTRIBUTION (Cont.)

<u>Copies</u>		<u>Copies</u>	
Eagle-Picher Industries, Inc. Attn: D. R. Cottingham J. Dines D. L. Smith J. Wilson		Duracell Int., Inc Attn: B. McDonald Battery Division South Broadway Tarrytown, NY 10591	1
Electronics Division, Couples Department P. O. Box 47 Joplin, MO 64801		Duracell Int., Inc. Attn: Dr. A. N. Dey Laboratory for Physical Science Burlington, MA 01803	1
Eagle-Picher Industries, Inc. Attn: P. E. Grayson Miami Research Laboratories 200 Ninth Avenue, N. E. Miami, OK 74354	1	Power Conversion, Inc. 70 MacQuesten Parkway S. Mount Vernon, NY 10550	1
Foote Mineral Company Attn: H. R. Grady Exton, PA 19341	1	Union Carbide Battery Products Division Attn: R. A. Powers P. O. Box 6116 Cleveland, OH 44101	1
Gould, Inc. Attn: S. S. Nielsen G. R. Ault 40 Gould Center Rolling Meadows, IL 60008	1	Wilson Greatbatch LTD. Attn: Library 1000 Wehrle Drive Clarence, NY 14030	1
GT & E Laboratory Attn: Dr. C. R. Schlaikjer 40 Sylvan Road Waltham, MA 02154	1	Yardney Electric Corporation Attn: Library A. Beachielli 82 Mechanic Street Pawcatuck, CT 02891	1
Honeywell, Inc. Attn: Library W. Ebner Defense Systems Division Power Sources Center 104 Rock Road Horsham, PA 19044	1	Callery Chemical Company Attn: Library Callery, PA 16024	1
Lockheed Missiles and Space Company, Inc. Attn: Library Lockheed Palo Alto Research Laboratory 3251 Hanover Street Palo Alto, CA 94304	1	Globe Union Inc. Attn: Dr. R. A. Rizzo 5757 N. Green Bay Avenue Milwaukee, WI 53201	1
		Battery Engineering Attn: Dr. N. Marincic 80 Oak Street Newton, MA 02164	1

## DISTRIBUTION (Cont.)

<u>Copies</u>	<u>Copies</u>
RAY-O-VAC Attn: R. Foster Udell 101 East Washington Avenue Madison, WI 53703	1 General Dynamics Pomona Div. Attn: Dr. Frank Hess Gordon Beckley P. O. Box 2507 1675 W. Mission Blvd. Pomona, CA 91766
TRW Systems Attn: Ed Moon, Rm. 2251 Bldg. 0-1 One Space Park Redondo Beach, CA 90278	1 Naval Weapons Support Center Attn: James A. Gucinski Bradley Secrest Vid Alminauskas (Code 30512) Crane, IN 47522
ALTUS Corporation Attn: Dr. Adrian E. Zolla 1610 Crane Court San Jose, CA 95112	1 Library of Congress Attn: Gift and Exchange Division Washington, D.C. 20540
SAFT America, Inc. Attn: Dr. R. J. Staniewicz 107 Beaver Court Cockeysville, MD 21030	Internal Distribution: 1 E231 2 E232 15 R33 25 R33 (P. Smith) 10 E342 (GIDEP) 1 1 G205 3 C72W (R.D. Johnson) 1
BMO/ENBE Attn: CAPT. A. S. Alanis Norton AFB CA 92409	
Norton AFB Attn: Code AFISC/SES CA 92409	

END

FEB.

1988

DTIC